D128 Render device not showing up

nomodeset in grub disabled d128render device. Remove nomodeset.

Revision #1
Created 5 August 2024 16:53:19 by TJN
Updated 5 August 2024 16:54:07 by TJN